



How to update PS2002 Firmware

Version: PS2002 Firmware V1.0C

Release note: Support SDHC SD V2.0 memory cards

Note:

1. All the updating steps are the same with VP6210/ VP6300/ VP6230/ VP6230i
VP6310/VP8350/VP8360/ VP8390. Here, use the VP8360 as instruction example.
2. For VP8350/VP8360/VP8390: Please check the USB mode under Options/System
is set as “**Mass Storage Device**”, not PictBridge/Media Player before updating.
Otherwise, the program will not recognize the device properly.

Step 1 : Check the Windows OS of your computer :

Windows 98 – Please install the driver before updating the firmware.


Windows 2000 – Do not support Windows 2000 SP1 & SP2. Please upgrade
to SP3 or SP4 and update the firmware without driver.

Windows XP – Support to update the firmware directly without driver.


Step 2 : Connect the device to the computer.

Step 3 : Double click ”Ps0Av42m.exe” to run the program.


You should see the following screen.




Step 4 : Press OK and you should see the following screen.





Step 5 : Tick "ISP_Ena"



Step 6 : Press " WIN9xISP" to begin updating.




Step 7 : When finished, some message as below will be displayed.



Step 8 : The update is finished. Press "Close" to close the program.

Step 9 : If you want to check if the correct information has been updated, remove the device from USB safely and power on the device again. Then re-insert into the USB port. After the computer recognizes the device, double click "Ps0Av42m.exe" again to check the current version.



The version has been updated to latest V1.0C.

If you have any questions or comments, please feel free mail to

service@vosonic.com.tw

Vosonic Technology Corporation Homepage: www.vosonic.com

7F., No.159 ,Hsien-Cheng 9th Road, Chu-Pei City , Hsi-Chu, Taiwan

TEL: +886 3 555 7745 FAX: +886 3 555 0390