

How to update Firmware-VP2160

Version: **V1.17e**

Release note: **Improve the compatibility with XD M type 2GB card and SanDisk Extreme III SD 1GB and 2GB card**

Step 1 : Check the Windows OS of your computer :

Windows 98 – Please install the driver before updating the firmware.

Windows 2000 – Do not support Windows 2000 SP1 & SP2. Please upgrade to SP3 or SP4 and update the firmware without driver.


Windows XP – Support to update the firmware directly without driver.

Windows Vista – Support to update the firmware directly without driver.


Step 2 : Connect the device to the computer.

Step 3 : Double click "Ps0Av44m.exe" to run the program.


You should see the following screen.




Step 4 : Press OK and you should see the following screen.





Step 5 : Tick "ISP_Ena"



Step 6 : Press " WIN9xISP" to begin updating.




Step 7 : When finished, some message as below will be displayed.



Step 8 : The update is finished. Press "Close" to close the program. Remove the USB connection and press "RESET" to power on the device again. Then the screen will show V1.17e.

Step 9 : If you want to check if the correct information has been updated, re-connect the device to computer. After the computer recognizes the device, double click "Ps0Av44m.exe" again to check the current version.



The version has been updated to latest V1.17e.

If you have any questions or comments, please feel free mail to
service@vosonic.com.tw

Vosonic Technology Corporation Homepage: www.vosonic.com

7F., No.159 ,Hsien-Cheng 9th Road, Chu-Pei City , Hsi-Chu, Taiwan

TEL: +886 3 555 7745 FAX: +886 3 555 0390