


## HOW TO UPDATE DSP FIRMWARE ( VP6230 / VP6310 / VP6210 / VP6300 )


Please plug in the AC adapter to avoid any low battery when updating.

### STEPS

1. Connect the device to your PC and save the file **FR0AXXXX.MMV** into the internal hard drive.
2. Remove the USB connection. Under stand-alone mode, find the **FR0AXXXX.MMV** file and press **OK** button to process the update.
3. It will ask “ Update to 0A-1.2.X ? “ , scroll to **YES** and press **OK** to enter next path.
4. The firmware upgrade will perform. It takes about 40 seconds.



5. When the message “ Successfully Updated” appears , press OK button to power off the device.



6. Power on the device again and go to OPTIONS / VERSION. You will find the firmware has been updated to version 1.2.5.

**Note:** After updating, the “Text Color” and “Cursor Color” will be changed to Black automatically. You can enter “Options” -> “Display” to adjust the color you prefer.